



Optical emission spectroscopy, mass spectrometry and spectroscopic ellipsometry measurements of the erosion of Ar/H₂ plasma-facing carbon surfaces

G. Ledru, T. Hansen, G. Yagci, S.V. Singh, D.C. Schram, R. Engeln

Plasma & Materials Processing (P&MP) - TU/e Eindhoven
(The Netherlands)



General activity of the group:
plasmas – surfaces interactions
(deposition of thin layers, etching)




Particular activity (R. Engeln, D. C. Schram):

- Characterization of an expanding thermal plasma (H_2)
- Plasma H_2 – surfaces interactions

Application:

plasma H_2 – carbon interactions

Fusion device ITER



**Possible material for ITER
divertor:**


**Carbon Fiber Composite
(CFC)**

ITER divertor hits by:

1-10 eV ions


$10^{24} \text{ m}^{-2} \cdot \text{s}^{-1}$ particle flux

Carbon erosion by hydrogen



J. Roth *et al*, *J. of Nucl. Mater.* **337-339**, 970-974 (2005).

No measurements in the transition between constant and decreasing erosion yield



J. Roth *et al*, *J. of Nucl. Mater.* **337-339**, 970-974 (2005).

- ▶ **Motivation**

- ▶ Several works about interaction plasma-surfaces in the group
- ▶ Importance of the effect of hydrogen on carbon in ITER



- ▶ **Experimental setup**

- ▶ Using different kinds of diagnostics to get more informations about the different processes

- ▶ **Results**

- ▶ Optical Emission Spectroscopy (OES)
- ▶ Mass Spectrometry
- ▶ Ex-situ Spectroscopic Ellipsometry (SE)

- ▶ **Summary**




- Ar/H₂ plasma (45 scc/s Ar; 10 scc/s H₂)
- I = 50 A
- T_{sample} = 293 K

Different diagnostics:

- Optical Emission spectroscopy
- Mass spectrometry
- Ex-situ Spectroscopic Ellipsometry

Principle of SE



Measurement of the change in the light polarization state upon reflection on a sample:

$$\rho = \frac{r^p}{r^s} = \tan \Psi e^{i\Delta}$$

Ψ and Δ can be related to the complex refractive index \tilde{n} and therefore used to obtain the dielectric constants ϵ_1 and ϵ_2 (n and k)

Transition pure Ar - Ar/H₂ plasma







- Measurements done with Ar/H₂ plasma
- Possibility to control hydrogen ions flux with Ar/H₂ mixture
- Effect of Ar ions on carbon samples?



- Carbon samples exposed to a pure argon plasma
- Ex-situ SE on samples before and after exposure



Erosion rates by argon ions:



- 0.14 nm/s


















No hydrocarbons detected between 50 amu and 100 amu




Always impurities like N_2 and H_2O



- **Mass spectrometry less efficient to determinate erosion rate:**
 fraction of eroded particle sticks to wall
- **Another kind of diagnostic** must be used to calculate erosion yield

M. Balden and J. Roth, *J. of Nucl. Mater.* **280**, 39-44 (2000).



Erosion rate: 2.26 ± 0.21 nm/s

- ▶ **Erosion rate determine for 1 kind of sample hardness**
 - ▶ Radicals like CH detected by OES,
 - ▶ Mass spectrometry less efficient to calculate erosion yield,
 - ▶ Erosion rate determinate with good precision with ex-situ SE.

Outlook

- ▶ In-situ SE,
 - ▶ Measurement of atomic hydrogen density by using TALIF,
 - ▶ Measurement of ionic hydrogen density by using a langmuir probe.
-

- ▶ **Many thanks for skillful technical assistance to**
 - Ries van de Sande,
 - Janneke Zeebregts,
 - Herman de Jong,
 - Bertus Hüsken

This work is part of the research program of the Netherlands Foundation for Fundamental Research on Matter (FOM) and is partially founded by Euratom. It is also financially supported by the Netherlands Organization for Scientific Research (NWO).



Euratom

